

Engine is not running.

Ignition switch  
ON  
OFF

Illuminating

All SRT codes  
are set.

MIL

Turning off

Illuminating

Any SRT codes  
are not set.

MIL

Turning off

Time

20 sec.

10 sec.

MIL starts  
blinking.

