






Low tire pressure warning lamp blinking timing	Activation tire position
<div> <div>ON</div>  <div>OFF</div> </div> <div> a : 0.3 sec. b : 1.3 sec. </div>	Front LH
<div> <div>ON</div>  <div>OFF</div> </div> <div> a : 0.3 sec. b : 1.3 sec. </div>	Front RH
<div> <div>ON</div>  <div>OFF</div> </div> <div> a : 0.3 sec. b : 1.3 sec. </div>	Rear RH
<div> <div>ON</div>  <div>OFF</div> </div> <div> a : 0.3 sec. b : 1.3 sec. </div>	Rear LH
<div> <div>ON</div>  <div>OFF</div> </div> <div> a : 2 sec. b : 0.2 sec. </div>	All tires