



* : ECM determines the start signal status by the signals of engine speed and battery voltage.

➡ : This signal is sent via the CAN communication line.