



*:ECM determines the start signal status by the signals of engine speed and battery voltage.