


ENGINE CONTROL SYSTEM

Connector No.	F34
Connector Name	TURBOCHARGER BOOST CONTROL SOLENOID VALVE
Connector Type	BS02FB-AHY-S



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	GR	-

Connector No.	F37
Connector Name	WIRE TO WIRE
Connector Type	RH06FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	W	-
3	B	-

Connector No.	F45
Connector Name	GAMSHAFT POSITION SENSOR (PHASE) (BANK 2)
Connector Type	RH03FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	V	-
3	Y	-

Connector No.	F46
Connector Name	AIR CUT SOLENOID VALVE (BANK 2)
Connector Type	HS02FB-6V



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	F47
Connector Name	WIRE TO WIRE
Connector Type	RS06FB-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	SHIELD	-
3	W	-
4	O	-
5	SHIELD	-
6	W	-

Connector No.	F48
Connector Name	WIRE TO WIRE
Connector Type	RS08FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	-
3	LG	-
4	P	-
5	W	-
6	R	-
7	SB	-
8	Y	-

Connector No.	F51
Connector Name	ENGINE COOLANT TEMPERATURE SENSOR
Connector Type	E02FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	O	-

Connector No.	F52
Connector Name	HEATED OXYGEN SENSOR 2 (BANK 2)
Connector Type	AFZ04FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	R	-
3	W	-
4	GR	-