



*: ECM determines the start signal status by the signals of engine speed and battery voltage.

➡: This signal is sent via the CAN communication line.