
















| SYMBOL  | DESCRIPTION   |   | SYMBOL  | DESCRIPTION                             |
|---|---|---|---|---|
|  | Tightening torque<br>The tightening torque specifications of bolts and nuts may be presented as either a range or a standard tightening torque. |  : N•m (kg-m, ft-lb) |  | Always replace after every disassembly. |
|  |   |  : N•m (kg-m, in-lb) |  | Apply petroleum jelly.                  |
|   | Should be lubricated with grease. Unless otherwise indicated, use recommended multi-purpose grease.   |   |  | Apply molybdenum added petroleum jelly. |
|  | Should be lubricated with oil.  |   |  | Apply ATF.                              |
|  | Sealing point   |   |  | Select with proper thickness.           |
|   | Sealing point with locking sealant.   |   |  | Adjustment is required.                 |
|   | Checking point  |   |   |   |