



*1 : This sensor is not used to control the engine system under normal conditions.

*2 : ECM determines the start signal status by the signals of engine speed and battery voltage.

---> : This signal is sent via the CAN communication line.