

BATTERY

FUSE BLOCK (J/B)

BCM (BODY CONTROL MODULE)

POWER WINDOW MAIN SWITCH (D8)

POWER WINDOW SUB-SWITCH (D38)

DRIVER SIDE POWER WINDOW MOTOR (D10)

PASSENGER SIDE POWER WINDOW MOTOR (D40)

Wiring Details:

- Battery:** 40A I, 10A 10, 7A, 91, E106, M6.
- BCM (BODY CONTROL MODULE):** 1, 11, 150, 124, 2, 3, 13, M119, M119, M123, M95.
- Power Window Main Switch (D8):** 9, 40, 10, 10, 2, 7, 6, 2, 10, 3, 11, 4, 3, 1, 8, 8, 15, M5, M11.
- Power Window Sub-Switch (D38):** 9, 40, 10, 10, 11, 12, 13, 14, 11, 3, 6, 7, 5, 15, 16, 14, 8, 15, M124, M95.
- Driver Side Power Window Motor (D10):** 10, 3, 11, 4, 3, 1, 8, 8, 15, M5, M11.
- Passenger Side Power Window Motor (D40):** 15, M124, M95.