

## INTELLIGENT KEY SYSTEM / ENGINE START FUNCTION

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH




93	V	ON IND
96	SB	CONTROL DEVICE POWER SUPPLY
97	L	S/L CONDITION 1
98	R	S/L CONDITION 2
99	G	SHIFT P
103	LG	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	P	S/L UNIT POWER SUPPLY
111	Y	S/L UNIT COMM

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Connector No.	M131
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR




Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-
73	G	ROOM ANT2+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	IMMOBI ANTENNA CONTROL
81	L	IMMOBI ANTENNA SIGNAL
83	Y	KEYLESS ENTRY RECEIVER COMM
89	BR	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL OUTPUT

Terminal No.	Color of Wire	Signal Name [Specification]
116	SB	STOP LAMP SW 1
118	P	STOP LAMP SW 2
124	LG	PASSENGER DOOR SW
134	GR	LOCK IND
137	L	RECEIVER GND
140	BR	SHIFT N/P
141	G	SECURITY INDICATOR
150	GR	DRIVER DOOR SW

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
4	BR	-
5	GR	-
6	Y	-
7	V	-
8	G	-

Connector No.	M134
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	JAB04FB



Connector No.	M146
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	GND
2	Y	SIGNAL OUTPUT
4	LG	BATTERY

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-