


BRAKE CONTROL SYSTEM

Connector No.	B252
Connector Name	WIRE TO WIRE
Connector Type	TH12MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	G	-
5	V	-
10	GR	-
11	LG	-

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
25	O	-

Connector No.	E27
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	R	-

Connector No.	E41
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AEZ43FB-AJZ4



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	UBMR
2	V	DIAG-K
3	GR	VDC OFF SW
4	W	BLS
6	G	MODE SW
11	Y	CAN-H
15	P	CAN-L
16	B	GND
26	W	CAN-L
27	BR	G SENSOR GND
29	O	UZ

30	L	CAN-H
32	O	UBVR
33	W	DS FR
34	O	DP FR
35	Y	UP LAMP
36	L	DP RL
37	R	DS RL
38	V	BRAKE FLUID LEVEL SW
39	G	G SENSOR POWER
42	V	DS RR
43	LG	DP RR
44	SB	DN LAMP
45	W	DP FL
46	R	DS FL
47	B	GND

Connector No.	E47
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	B/W	-

Connector No.	E60
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	W	-