

BOSE AUDIO WITH NAVIGATION SYSTEM

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB40FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M66
Connector Name	A/C AUTO AMP.
Connector Type	SAB40FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	CAN-H
2	P	CAN-L

Connector No.	M71
Connector Name	DISPLAY UNIT
Connector Type	TH24FW-NH



12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
2	Y	BATTERY
3	P	ACC
4	SHIELD	SHIELD
5	SB	AUX IMAGE GND
6	G	RGB (G: GREEN) SIGNAL
7	SHIELD	SHIELD
8	R	HP
9	W	RGB AREA (YS) SIGNAL
11	BR	COMM (CONT->DISP)
13	B	GND

15	V	AUX IMAGE SIGNAL
17	R	RGB (R: RED) SIGNAL
18	B	RGB (B: BLUE) SIGNAL
19	W	RGB SYNC
20	B	VP
21	SHIELD	SHIELD
22	Y	COMM (DISP->CONT)
23	SHIELD	SHIELD

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FW-NH



2	4	6	8	10	12	14	16
1	3	5	7	9	11	13	15

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
3	V	ACC
6	G	AV COMM (H)
8	R	AV COMM (L)
9	BR	SW GND
14	SB	DISK EJECT SIGNAL

Connector No.	M76
Connector Name	CENTER SPEAKER
Connector Type	TK02FBR



2	1
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-

Connector No.	M80
Connector Name	AV CONTROL UNIT
Connector Type	TH18FW-CS2



19	1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18	20

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	BOSE AMP. ON SIGNAL [With BOSE audio]
2	L	SOUND SIGNAL FRONT LH (+) [With BOSE audio]
3	P	SOUND SIGNAL FRONT LH (-) [With BOSE audio]
4	V	SOUND SIGNAL REAR LH (+) [With BOSE audio]
5	LG	SOUND SIGNAL REAR LH (-) [With BOSE audio]
6	V	STRG SW A
7	V	ACC
9	R	ILLUMINATION
10	SHIELD	SHIELD
11	R	SOUND SIGNAL FRONT RH (+) [With BOSE audio]
12	G	SOUND SIGNAL FRONT RH (-) [With BOSE audio]

13	BR	SOUND SIGNAL REAR RH (+) [With BOSE audio]
14	Y	SOUND SIGNAL REAR RH (-) [With BOSE audio]
15	GR	STRG SW GND
16	SB	STRG SW B
19	Y	BATTERY