


ENGINE CONTROL SYSTEM


Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK36FW-NS10



26	L	-
27	P	-
28	LG	-
29	R	-
30	L	-
31	R	-
32	W	-
33	W	-
34	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	R	-
3	W	-
6	O	-
7	B	-
8	B	-
9	W	-
13	SB	-
14	LG	-
15	G	-
16	W	-

Connector No.	F122
Connector Name	FUEL INJECTOR No. 2
Connector Type	HS02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	R/W	-

Connector No.	F123
Connector Name	FUEL INJECTOR No. 3
Connector Type	HS02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	R/Y	-

Connector No.	F120
Connector Name	WIRE TO WIRE
Connector Type	RS08MGY-PR




Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
3	R/Y	-
4	R/B	-
5	W/L	-
6	V/R	-
7	R/L	-
8	R/W	-

Connector No.	F124
Connector Name	FUEL INJECTOR No. 4
Connector Type	HS02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	R/L	-

Connector No.	F121
Connector Name	FUEL INJECTOR No. 1
Connector Type	HS02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	R/B	-

Connector No.	F125
Connector Name	FUEL INJECTOR No. 5
Connector Type	HS02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	W	-