

2. Work and Diagnosis procedure

1. Test Group Number and Test Group Title



4. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check the continuity between ECT sensor harness connector and ECM harness connector.

ECT sensor		ECM		Continuity
Connector	Terminal	Connector	Terminal	
F17	2	F102	84	Existed

4. Also check harness for short to ground and short to power.

Connector Number

Is the inspection result normal?

3. Question

YES>>GO TO 5.

NO>>Repair open circuit or short to ground or short to power in harness or connectors.

3. Result

4. Action