


TRANSMISSION CONTROL SYSTEM

Connector No.	B50
Connector Name	TRANSMISSION UNIT
Connector Type	RK22FGY



Terminal No.	Color of Wire	Signal Name [Specification]
37	R	CLUTCH A SOLENOID VALVE (+)
38	LG	CLUTCH A SOLENOID VALVE (-)
40	BR	CLUTCH A PRESSURE SENSOR (+)
41	R	CLUTCH A PRESSURE SENSOR SIGNAL
42	G	CLUTCH B SOLENOID VALVE (+)
43	Y	CLUTCH B SOLENOID VALVE (-)
45	L	FLUID TEMPERATURE SENSOR (+)
46	SB	FLUID TEMPERATURE SENSOR (-)
47	W	CLUTCH A PRESSURE SENSOR (-)
48	V	LINE PRESSURE SOLENOID VALVE (+)
49	O	LINE PRESSURE SOLENOID VALVE (-)

51	Y	CLUTCH B PRESSURE SENSOR (+)
52	L	CLUTCH B PRESSURE SENSOR SIGNAL
53	G	CLUTCH B PRESSURE SENSOR (-)
54	BR	LUBRICATING FLOW SOLENOID VALVE (+)
55	W	LUBRICATING FLOW SOLENOID VALVE (-)

Connector No.	B54
Connector Name	TCM RELAY
Connector Type	M06FBR-R-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	R	-
3	G	-
5	O	-
6	W	-
7	R	-

Connector No.	B55
Connector Name	BACK-UP LAMP RELAY
Connector Type	M06FBR-R-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	LG	-
6	P	-
7	Y	-

Connector No.	B121
Connector Name	WIRE TO WIRE
Connector Type	RH06MB




Terminal No.	Color of Wire	Signal Name [Specification]
5	B	-
6	L	-

Connector No.	B122
Connector Name	PARK POSITION SWITCH
Connector Type	RK02FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
61	P	-
62	L	-
69	P	-
70	L	-

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
25	O	-