

TIRE PRESSURE MONITORING SYSTEM

Connector No.	E104
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
5	P	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



6	15
6	15
16	25
16	25
26	35
26	35
36	45
36	45
46	55
46	55
56	65
56	65
66	75
66	75
76	85
76	85
86	95
86	95

Terminal No.	Color of Wire	Signal Name [Specification]
76	LG	-
77	V	-
78	BR	-
79	W	-
87	R	-
88	L	-
89	O	-
90	G	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	INS06FW-M2



3A	2A	1A
8A	7A	6A
5A	4A	

Terminal No.	Color of Wire	Signal Name [Specification]
2A	G	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



1	2	3	4	5
1	2	3	4	5
6	7	8	9	10
6	7	8	9	10
11	12	13	14	15
11	12	13	14	15
16	17	18	19	20
16	17	18	19	20
21	22	23	24	25
21	22	23	24	25
26	27	28	29	30
26	27	28	29	30
31	32	33	34	35
31	32	33	34	35
36	37	38	39	40
36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
76	LG	-
77	R	-
78	BR	-
79	W	-
87	R	-
88	L	-
89	G	-
90	P	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



1	2	3	4	5
1	2	3	4	5
6	7	8	9	10
6	7	8	9	10
11	12	13	14	15
11	12	13	14	15
16	17	18	19	20
16	17	18	19	20
21	22	23	24	25
21	22	23	24	25
26	27	28	29	30
26	27	28	29	30
31	32	33	34	35
31	32	33	34	35
36	37	38	39	40
36	37	38	39	40

Terminal No.	Color of Wire	Signal Name [Specification]
31	GR	-
32	L	-
33	V	-
34	O	-
69	P	-
70	L	-

Connector No.	M14
Connector Name	LOW TIRE PRESSURE WARNING CONTROL UNIT
Connector Type	TH32FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	CAN-(L)
2	L	CAN(H)
3	O	RL TUNER (SIG)
4	L	RR TUNER (SIG)
5	R	FL TUNER (SIG)
6	W	FR TUNER (SIG)
7	SB	RR TUNER (PWR)
8	GR	RL TUNER (PWR)
9	R	FR TUNER (PWR)
10	LG	FL TUNER (PWR)
12	W	SW SIG

15	G	IGN
19	R	RR TUNER (RSSI)
20	O	RL TUNER (RSSI)
21	P	FR TUNER (RSSI)
22	G	FL TUNER (RSSI)
23	GR	RR TUNER (GND)
24	V	RL TUNER (GND)
25	L	FR TUNER (GND)
26	BR	FL TUNER (GND)
30	G	FLASHER SIG
32	B	GND

Connector No.	M23
Connector Name	TIRE PRESSURE WARNING SWITCH
Connector Type	TK02FW



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-