



CHARGING SYSTEM



CHARGING SYSTEM

Connector No.	E1
Connector Name	FUSIBLE LINK HOLDER
Connector Type	L02FBR-MC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-

Connector No.	E49
Connector Name	WIRE TO WIRE
Connector Type	RH08MB




Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-
4	P	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
25	BR	-

Connector No.	E251
Connector Name	WIRE TO WIRE
Connector Type	RH08FB



Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-
4	V	-

Connector No.	E252
Connector Name	FUSIBLE LINK HOLDER
Connector Type	24340.79905



Terminal No.	Color of Wire	Signal Name [Specification]
6	B	-

Connector No.	E253
Connector Name	ALTERNATOR
Connector Type	24340.65F45



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	B

Connector No.	E254
Connector Name	ALTERNATOR
Connector Type	HS03FB



Terminal No.	Color of Wire	Signal Name [Specification]
2	BR	L
3	V	S


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
12C	W	-


CHARGING SYSTEM

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
25	BR	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	W	IGNITION POWER SUPPLY
28	BR	ALTERNATOR