

ENGINE CONTROL SYSTEM


Connector No.	E7
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4



Terminal No.	Color of Wire	Signal Name [Specification]
48	L	-
49	P	-
51	LG	-
53	SB	-
54	W	-
55	O	-
56	R	-
57	G	-
69	O	-
70	G	-
71	SB	-

74	LG	-
77	B/W	-

Connector No.	E9
Connector Name	JPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
97	Y	-

Connector No.	E14
Connector Name	AIR PUMP
Connector Type	SMZ02FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	B/W	-
2	R	-

Connector No.	E17
Connector Name	COOLING FAN RELAY 1
Connector Type	SJZ01FGY-SNZ2



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	O	-
3	O	-
5	R	-

Connector No.	E19
Connector Name	COOLING FAN RELAY 2
Connector Type	SJZ01FGY-SNZ2



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	P	-
5	W	-

Connector No.	E22
Connector Name	SECONDARY AIR INJECTION SYSTEM MASS AIR FLOW SENSOR
Connector Type	E04FBR-RS-LGY



Terminal No.	Color of Wire	Signal Name [Specification]
2	P	-
3	V	-
4	LG	-

Connector No.	E35
Connector Name	COOLING FAN CONTROL MODULE 1
Connector Type	Sumitomo 6189-0588



Terminal No.	Color of Wire	Signal Name [Specification]
1	B/W	-
2	Y	-
3	R	-