



CAUTION: In user mode, when the “AIR BAG” warning lamp is not blinking, switching to Diagnosis mode by ignition switch operation is not possible.

In Diagnosis mode, when no malfunction is detected, user mode can be switched on by turning the ignition switch from OFF to ON.