



ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
25	O	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
4	O	-

Connector No.	E203
Connector Name	WIRE TO WIRE
Connector Type	RH06MB




Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	B	-

Connector No.	E207
Connector Name	POWER STEERING SOLENOID VALVE
Connector Type	RH02FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	F37
Connector Name	WIRE TO WIRE
Connector Type	RH06FB




Terminal No.	Color of Wire	Signal Name [Specification]
4	LG	-
5	B	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK36FW-NS10




Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-
12	LG	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
4	G	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
12	L	VEHICLE SPEED SIGNAL (2-PULSE)