

IGNITION POWER SUPPLY FUSE No. 44

| | |
|----------------|---------------------|
| Connector No. | F124 |
| Connector Name | FUEL INJECTOR No. 4 |
| Connector Type | HS02FGY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W/L | - |

| | |
|----------------|---------------------|
| Connector No. | F125 |
| Connector Name | FUEL INJECTOR No. 5 |
| Connector Type | HS02FGY |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W/L | - |

| | |
|----------------|---------------------|
| Connector No. | F126 |
| Connector Name | FUEL INJECTOR No. 6 |
| Connector Type | HS02FGY |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W/L | - |

| | |
|----------------|-----------------|
| Connector No. | M6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 46 | LG | - |
| 94 | W | - |

| | |
|----------------|--------------------|
| Connector No. | M107 |
| Connector Name | ECM |
| Connector Type | RH24FGY-RZ8-R-LH-Z |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 106 | LG | IGNSW |

| | |
|----------------|--------------|
| Connector No. | M116 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK36MW-NS10 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 9 | W | - |