


BATTERY POWER SUPPLY FUSIBLE LINK No. 1

|                |                 |
|----------------|-----------------|
| Connector No.  | M62             |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | M02FW-P-LC      |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | W             | —                           |
| 2            | W             | —                           |

|                |                 |
|----------------|-----------------|
| Connector No.  | M117            |
| Connector Name | WIRE TO WIRE    |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 100          | W             | —                           |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M118                      |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | M03FB-LC                  |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | BAT (F/L)                   |