

ENGINE CONTROL SYSTEM

Connector No.	F126
Connector Name	FUEL INJECTOR No. 6
Connector Type	HS02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W/L	-
2	V/R	-

Connector No.	F201
Connector Name	WIRE TO WIRE
Connector Type	RS06MB



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	SHIELD	-
3	W	-
4	R	-
5	SHIELD	-
6	W	-

Connector No.	F202
Connector Name	KNOCK SENSOR (BANK 1)
Connector Type	E02FG-RS-LGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SHIELD	-

Connector No.	F203
Connector Name	KNOCK SENSOR (BANK 2)
Connector Type	E02FG-RS-LGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	SHIELD	-

Connector No.	F204
Connector Name	ENGINE OIL TEMPERATURE SENSOR
Connector Type	E02FGY-RS




Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color of Wire	Signal Name [Specification]
2A	G	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3B	P	-
6B	Y	-