


BATTERY POWER SUPPLY FUSE No. 50

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH20FW-CS16-M4



Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-

Connector No.	B250
Connector Name	EVAP CANISTER VENT CONTROL VALVE
Connector Type	E02FB-RS




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-

Connector No.	E3
Connector Name	WIRE TO WIRE
Connector Type	RS08FB-PR




Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
5	P	-

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
10	W	-

Connector No.	E7
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4



Terminal No.	Color of Wire	Signal Name [Specification]
49	P	-
53	SB	-

Connector No.	E22
Connector Name	SECONDARY AIR INJECTION SYSTEM MASS AIR FLOW SENSOR
Connector Type	E04FBR-RS-LGY




Terminal No.	Color of Wire	Signal Name [Specification]
2	P	-

Connector No.	E51
Connector Name	AIR PUMP RELAY
Connector Type	24347 9F900



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-

Connector No.	E52
Connector Name	AIR CUT SOLENOID VALVE RELAY
Connector Type	MS02FL-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-