


## Example

(SWITCH CHART)

WIPER SWITCH					
	OFF	INT	LO	HI	WASH
1					<input type="radio"/>
2				<input type="radio"/>	
3	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		
4	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5		<input type="radio"/>			
6		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

(SWITCH DIAGRAM)



Continuity circuit of wiper switch

SWITCH POSITION	CONTINUITY CIRCUIT
OFF	3-4
INT	3-4, 5-6
LO	3-6
HI	2-6
WASH	1-6