

Washer level switch

ON

OFF

Low washer fluid warning

ON

OFF

180 sec
or less

180 sec
or more

30 sec
or less

30 sec
or more

