


The tachometer moves while driving.



Warning lamps turn ON.

The speedometer does not move while driving.

The shift position is not indicated.