


## ENGINE CONTROL SYSTEM

Connector No.	B229
Connector Name	CONDENSER
Connector Type	M02FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	B	-

Connector No.	B230
Connector Name	FUEL PUMP CONTROL MODULE
Connector Type	TM10FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	SHIELD	SHIELD
5	B	GROUND
6	G	FUEL PUMP(-)
7	BR	FUEL PUMP(+)
8	V	FPC INPUT SIGNAL
9	SB	DIAG OUTPUT SIGNAL
10	Y	BATTERY

Connector No.	B242
Connector Name	SUB FUEL PUMP RELAY
Connector Type	MS02FL-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	R	-
5	O	-

Connector No.	B250
Connector Name	EVAP CANISTER VENT CONTROL VALVE
Connector Type	E02FB-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	L	-

Connector No.	B251
Connector Name	EVAP CONTROL SYSTEM PRESSURE SENSOR
Connector Type	E03FGY-RS




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	LG	-
3	BR	-

Connector No.	E3
Connector Name	WIRE TO WIRE
Connector Type	RS08FB-PR




Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	LG	-
3	W	-
5	P	-
6	V	-
7	SHIELD	-
8	G	-

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color of Wire	Signal Name [Specification]
10	W	-
12	B/W	-
13	R	-

Connector No.	E6
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH08FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B/Y	-
42	G	-