





Ground Inspection



Remove bolt (screw).

Inspect mating surfaces
for tarnish, dirt, rust, etc.
Clean as required to
assure good contact.

Reinstall bolt (screw)
securely.