


BOSE AUDIO WITH NAVIGATION SYSTEM

Connector No.	B35
Connector Name	WOOFER
Connector Type	NS08FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	SOUND SIGNAL WOOFER (-)
2	P	SOUND SIGNAL WOOFER (+)
3	W	WOOFER AMP. ON SIGNAL
5	B	GND
6	R	BATTERY
7	B	GND
8	R	BATTERY

Connector No.	B40
Connector Name	REAR SPEAKER LH
Connector Type	TK02MBR-P




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	LG	-

Connector No.	B43
Connector Name	REAR SPEAKER RH
Connector Type	TK02MBR-P




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	—
2	O	—

Connector No.	B45
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	RH40FB-RZ8-L-LH-Z




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	CAN-H
15	P	CAN-L

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
61	P	—
62	L	—
69	P	—
70	L	—

Connector No.	B213
Connector Name	AWD CONTROL UNIT
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
8	L	CAN-H
16	P	CAN-L

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	G	-
3	L	- [With BOSE audio]
4	W	- [With BOSE audio]

Connector No.	D4
Connector Name	TWEETER LH
Connector Type	TK02MBR-P



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	—
2	G	—