



BRAKE CONTROL SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
69	P	—
70	L	—

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	—
2	O	—
3	BR	—
6	P	—
7	W	—
8	SB	—
9	LG	—
10	V	—
11	GR	—
12	G	—

Connector No.	B36
Connector Name	YAW RATE/SIDE/DECEL G SENSOR
Connector Type	AA206FB2




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	CAN-L
2	O	CAN-H
3	SB	BATTERY
5	BR	GND

Connector No.	B45
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	RH40FB-RZ8-L-LH-Z




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	CAN-H
15	P	CAN-L

Connector No.	B51
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
4	G	—
5	V	—
10	GR	—
11	LG	—

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
61	P	—
62	L	—
69	P	—
70	L	—

Connector No.	B213
Connector Name	AWD CONTROL UNIT
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
8	L	CAN-H
16	P	CAN-L

Connector No.	B249
Connector Name	REAR WHEEL SENSOR
Connector Type	RS04FGY-PR



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	—
2	G	—
3	LG	—
4	V	—