


BATTERY POWER SUPPLY

Connector No.	E29
Connector Name	FRONT SIDE MARKER LAMP LH
Connector Type	RK02FBR-DGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-

Connector No.	E41
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	AEZ43FB-AJZ4



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	UBMR
32	O	UBVR

Connector No.	E49
Connector Name	WIRE TO WIRE
Connector Type	RH08MB




Terminal No.	Color of Wire	Signal Name [Specification]
4	P	-

Connector No.	E51
Connector Name	AIR PUMP RELAY
Connector Type	Z4347.9F900



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	-

Connector No.	E52
Connector Name	AIR CUT SOLENOID VALVE RELAY
Connector Type	MS02FL-M2



Terminal No.	Color of Wire	Signal Name [Specification]
5	P	-

Connector No.	E58
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS08FB-PR




Terminal No.	Color of Wire	Signal Name [Specification]
5	R	-
7	BR	-
8	O	-

Connector No.	E63
Connector Name	FRONT SIDE MARKER LAMP RH
Connector Type	RK02FBR-DGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	E84
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS03FB-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
5	O	-