




Waterproof type



- ① Firmly grasp shell of connector housing at A.




- ② Push slider until connector pops or snaps apart.




- ③ Disconnect harness connector.


Non-waterproof type



- ① Firmly grasp shell of connector housing at A.



- ② Pull back on the slider while pulling apart male and female halves of connector.



- ③ Disconnect harness connector.