



BATTERY POWER SUPPLY

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
10	R	-
26	P	-
96	Y	-

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
5	R	-

Connector No.	B16
Connector Name	BOSE AMP.
Connector Type	SGA12FBR-SJA2




Terminal No.	Color of Wire	Signal Name [Specification]
11	Y	BATTERY

Connector No.	B18
Connector Name	AUDIO AMP. LH
Connector Type	NS10FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	BATTERY

Connector No.	B19
Connector Name	AUDIO AMP. RH
Connector Type	NS10FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	BATTERY

Connector No.	B35
Connector Name	WOOFER
Connector Type	NS08FBR-CS




Terminal No.	Color of Wire	Signal Name [Specification]
6	R	BATTERY
8	R	BATTERY

Connector No.	B45
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	RH40FB-RZ8-L-LH-Z



Terminal No.	Color of Wire	Signal Name [Specification]
9	P	BATT-1

Connector No.	B54
Connector Name	TCM RELAY
Connector Type	M06FBR-R-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	R	-
5	O	-
7	R	-