

BASE AUDIO WITH NAVIGATION SYSTEM

| | |
|----------------|--------------|
| Connector No. | M390 |
| Connector Name | WIRE TO WIRE |
| Connector Type | GT16C-1PP-HU |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | - | - |
| 2 | - | - |

| | |
|----------------|--------------|
| Connector No. | M391 |
| Connector Name | WIRE TO WIRE |
| Connector Type | GT16C-1S-HU |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | - | - |
| 2 | - | - |

| | |
|----------------|-------------------------|
| Connector No. | M392 |
| Connector Name | SATELLITE RADIO ANTENNA |
| Connector Type | GT16C-1PP-HU |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | - | - |
| 2 | - | - |

| | |
|----------------|--------------|
| Connector No. | R1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | P | - |
| 3 | L | - |

| | |
|----------------|------------|
| Connector No. | R5 |
| Connector Name | MICROPHONE |
| Connector Type | TK04FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | MICROPHONE SIGNAL |
| 2 | SHIELD | MICROPHONE GND |
| 4 | L | MICROPHONE VCC |